

## FIAM: External Fleet Maintenance Repairs

Job Aid: Set Work Order to a 'Work in Progress' Status

## Set Work Order to a 'Work in Progress' Status

Once the work order is in a 'quote approved' status and you are ready to start the repairs, you should set the Work Order status to 'Work in Progress' to inform CN that the job has started.




Setting the work order to Work in Progress is critical for updating the service event (PM) date in FleetWave.

## **Steps**


1

Go to the Fleet External module on the menu bar.




2

Use the search box to find the Work Order or Vehicle ID you are looking for.




Open the Work Order in edit mode by clicking on the paper-pencil icon .

Note that the work order should be at a **Quote Approved** status to move it to Work in Progress.





Set the Work Order header status to 'Work in Progress'.





The Work in Progress button is only visible if the work order is at **Quote Approved**.



## **NOTE**

The System sets the **Vendor Start Date** and **Vendor Start Time** to the present date and time the work has commenced. This can be edited if required.