




Prince George Intermodal Terminal | PRINCE GEORGE British Columbia

855 River Road, V2L 5M5



Terminal Hours

Day	Hours
Sunday	06:30 - 13:30
Monday	06:30 - 18:30
Tuesday	06:30 - 18:30
Wednesday	06:30 - 18:30
Thursday	06:30 - 18:30
Friday	06:30 - 18:30
Saturday	06:30 - 13:30



Crane Tent

PD01

TL01

AC34

PD02

Driver Room

Storage Building

CNTL parking

Office/Warehouse

Scale

Stop Signs

Staff Parking Lot

CNTL Entrance

Intermodal Garage

Wash Bay

D Lumber Yard

C Lumber Yard

Transload Shed

TL02

Additional Lumber Yard

Hill

Lumber Truck Entrance

A Lumber Yard

B Lumber Yard

Pad

25

24

23

22

21

20

19

18

17

16

15

14

13

12

11

10

9

8

7

6

5

Live Load Entrance

River Road