



WINTER SAFETY CHECKLIST – for those who enter CN Intermodal Terminals

Safety in the Terminal

During a winter storm, validate the need to send truckers to the terminal

Personal Protective Equipment (PPE) must be worn at all times on CN property

Do not use cellular phone/radio while driving a vehicle on CN property

- Even while being serviced by a crane

Remain focused at all times, reduce speed in the terminal when conditions are changing and when passing near workers

Drivers must stop at all crossings within the terminal

Mobile cranes have the right of way in the yard at all times.

- Reduce speed during wintertime, as the road could be slippery

Remain in vehicle at all times – only exception to unlock chassis locks

- It is strictly forbidden to exit your vehicle while waiting in line at the gate
- Drivers must wear appropriate anti-slip footwear for when they are required to exit the vehicle
- Extra care must be taken when stepping down from any vehicle during winter, as the road may be slippery

Drivers must use designated corridors to walk to the main building when necessary

It is strictly forbidden to climb onto mobile cranes or railcars

Never back up in the portal area nor while waiting in line for a gate to free up

Snow Removal

All container roofs must be clear of ice and snow prior to entering terminal

- The terminal may turn away truckers not compliant with this notice

Follow major road access – do not go across container piles where snow may have accumulated

Once served, proceed towards the exit to complete transaction, unless there is a need to clear snow or ice from the roof

- A designated area is available for your driver in each terminal to clear the container roof prior to departure